



# Control panel

## Features

- Touchscreen to arm or disarm alarm
- Takes a photo when disarmed from screen
- Contains siren that sounds during alarm event
- 18-24 hours backup battery to provide essential services during a power outage
- Alerts you to power failure and power restore
- Displays Morepork alerts and sensor status
- Photo frame screensaver so you can upload your own pictures

## Setup

- Indoor use only
- Requires power
- Works off the Spark mobile network - minimum one bar of service required
- Set up on a flat horizontal surface or table top
- We recommend your control panel be centrally located in your home, and where possible away from items such as cordless phones, microwaves and broadband modem to maximise sensor range.

## Technical Details

Dimensions	(L) 21.6cm x (W) 16.5cm x (H) 3.8cm
Weight	925g
Power supply	12V DC
Battery backup	Lithium ion 2500mAh (included)
Siren	91 dBA
Connectivity	Spark mobile network
Front camera	0.3MP fixed focus
Operating temperature	-10°C - 50°C